

COLOR CONFORMANCE CONFERENCE '25

**New Port Richey, FL (Tampa North)
January 28–30, 2025**



COLOR CONFORMANCE CONFERENCE '25



David
PRESIDENT



Pierre
TECHNICAL SERVICES



Larry
CUSTOMER SUCCESS



Beth
OFFICE MANAGER



Krzysztof
CHIEF ARCHITECT



Zbigniew
UI DESIGN



Dominik
HEAD DEVELOPMENT



Krzysztof
CC APPS DEVELOPER



Jan
CC APPS DEVELOPER

Your Hosts- Welcome!!!



COLOR CONFORMANCE
CONFERENCE '25

Where are You in your Color Control Journey?

January 28, 2025

Presented by

David Hunter

Agenda

Reality of Color Quality Communications Today

What is Manufacturing?

- Process Control vs. Color Conformance

Moving from Subjective to Scientifically based Communications

- Quantifying color expectations
- Linking color expectations to print capabilities

Productivity and Profitability

- Starts at the Operator – Know when producing waste
- Reporting efficiency and effectiveness in print process

Conclusion

When Dealing with Customers...

Reality of Print Approvals- Salable Print

- Proofing “Match”
- G7 Compliant
- ISO Standards
- Score Carding

Let's take a closer look at the reality of each...

Reality of Print Approvals



Approve – How to quantify acceptance?

- No easy way to quantify match
- Subjective
- Visual eye balling


Doesn't ensure color quality nor consistency

Reality of G7

G7 is a methodology delivering shared common appearance

- G7 never promised color “match”
- G7 Methodology based Gray Balance & NPDC, process control **not Color**
- G7 doesn't quantify a color match...

Doesn't ensure color quality



Reality of ISO Standards

Formulas that describe a way of printing...

- ✦ ISO 12647-2 to 6 Printing Standards
- ✦ ISO 12647-7 Proofing Standards – process control tolerances
- ✦ ISO 15339 Printing Standards (based on G7), no tolerances




No Ability to audit ISO print standards in North America

Reality of Score Carding

Process Score Cards don't predict color match

- 5 points for each primary within 3 ΔE etc... process control
- 85 points – Good Match? Can't relate to customer expectations
- **Can't compare printers to one another:** only to reference

Doesn't ensure color quality


		
1.1	87.0	✓
5.7	38.2	✗
1.4	84.0	✓
3.4	68.6	✓
1.6	86.6	✓

Process Control vs Color Conformance

What is Manufacturing

- Taking raw materials and creating products that consistently meet customer **expectations**
- **Process Control:** Ensuring a process is predictable, stable and consistently operates at a target level of performance, with only normal variation
 - Proofing, ISO Standards, Score Cards, G7 methodology
- **Color Conformance:** Manufacturing quality color means meeting a customers color requirements/**expectations**, producing salable goods
 - Introducing: E-Factor metric
 - Depends on Process Control, better the process control, better the E-Factor

Manufacturing – products meeting Customer expectations



Where is Your Company At?




GRAPHIC ARTS

PRINT MANUFACTURING

SUBJECTIVE PERSONAL-BASED JUDGMENT

METRICAL-BASED JUDGMENT **SCIENTIFIC**

VISUAL ASSESSMENT • COMPARATIVE COLOR MEASUREMENT • ADVANCED COLOR MEASUREMENT



VISUAL

Personal perception-based comparison to physical standard

- no knowledge required
- expensive and time-consuming personal supervision
- dependent on the person
- lighting conditions related
- uncontrolled metamerism
- no repeatability
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints

BASIC INSTRUMENTAL

Instrument-based comparison to physical standard

- numerically expressed color differences
- expensive and time-consuming personal supervision
- uncontrolled metamerism
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

COLORIMETRIC AIM

Instrument-based comparison to colorimetric standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- the possibility of remote control
- limited color definition
- only one lighting condition specified
- uncontrolled metamerism
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

SPECTRAL AIM

Instrument-based comparison to spectral standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- lighting condition independent
- controlled metamerism
- the possibility of remote control
- trackable instrument precision and stability
- optional inter-instrument agreement harmonization

Customer Expectations – How Do You Know?

Experience – Multiple Accepted and Rejected Job

- Person at printer that looked at jobs, understand difference

Visual impression



Reference



G7 Pass

≠

Actual



G7 Pass

Objective numbers

Difference = ?

© Copyright 2025  ChromaChecker

Customer Expectations – How Do You Know?

Experience – Multiple Accepted and Rejected Job

- Person at printer that looked at jobs, understand difference

Visual impression



Reference



G7 Pass

=

Actual



G7 Pass

Objective numbers

Difference = ?

Customer Expectations – How Do You Know?

Experience – Multiple Accepted and Rejected Job

- Person at printer that looked at jobs, understand difference
- Tribal Knowledge – human subjectivity – can't translate
- Results in rejected jobs – waste, loss of profitability

Visual impression



Reference



G7 Pass

≠

Actual



G7 Pass


Objective numbers

Difference = ?

What If?

We Could Use One Number to assess Salability

- Assess customer's Expectations (E-Factor) with number



- If Production is manufactured inside tolerance = Salable!

What If? Color Conformance!


We Could Use One Number to Assess Salability

- Assess customer's expectations with this number
- Use to compare difference between print and reference
- Use to compare any two printing conditions to each other
- One number for operators to know if salable or waste
- Different tolerances for different types of work

But if we know the Range of Acceptability...

Industry Studies – Print Buyer Expectations

- 93%+ Print Buyers will accept <3 E-Factor
- 95%+ Print Buyers won't accept >8 E-Factor



Industry Results: Color Conformance


Industry Survey

- For first time in Industry, can use “**One**” number to determine if match is acceptable or not most of time
 - E-Factor: 1-3 = Good or Excellent Match by vast majority
 - E-Factor: 3-8 = **Danger Zone: Unacceptable to some**
 - E-Factor: 8+ = Unacceptable by vast majority
- **Danger Zone: most printing today**
 - Unknown if Customer will accept, cause customer rejection and need to reprint (costing time and money) killing profitability
 - Most printers today manufacture in 4-6 E-Factor = **Danger Zone**

But if we know the Range of Acceptability...


Industry Studies – Print Buyer Expectations

- 93%+ Print Buyers will accept <3 E-Factor
- 95%+ Print Buyers won't accept >8 E-Factor



Determine Any Customer's Expectations

Free Web based exercise: <https://chromachecker.com/cee/en/start>



Printed version for \$99




Each page is marked with one of the icons:



Determine Any Printing Device's E-Factor

Match Printers to Reference (GRACoL)


- Each printer is a dart, within E-Factor tolerance?
- Do you know how your printers perform, every shift?



Color Match – Quantify How Close?

Define Plant Tolerance


- How close Required? Not only to reference, but to each other



Color Match – Quantify How Close?

Define Plant Tolerance


- How close is Required? E-Factor metric...



Color Match – Quantify How Close?

How Many of you know what your E-Factors are for each of your printing devices?


- How many of you are running a plant wide E-Factor Tolerance?



Link Color Expectation to Print Capabilities

Can Printer meet Customer Exceptions?

Manufacturing: Take raw materials, create a product that consistently meets customer expectations



Why Not Use G7 to define Color Match?

Both are G7 Compliant – but NOT ACCEPTABLE

- E-Factor = 7, not acceptable for many people
- Have multiple G7 prints, not match
- Not Color Conformance


 $= 7$



Actual Sample – HP Indigo: G7 Curves vs ICC Profiles

Better Process Control, better Color Conformance to GRACoL

- Apply G7 tone reproduction curve
 - Only affects tonality and gray balance



- Apply ICC Profiles, or ICC DeviceLinks
 - Affects Entire color space, CMY tints and Colors



Print Manufacturing: Salable Numbers

ROAD MAP TO ANALYTICS BASED PRINT MANUFACTURING

SUBJECTIVE

PERSONAL-BASED
JUDGMENT

METRICAL-BASED
JUDGMENT

SCIENTIFIC

VISUAL ASSESSMENT

COMPARATIVE COLOR MEASUREMENT

ADVANCED COLOR MEASUREMENT



VISUAL

Personal perception-based
comparison to physical standard

- no knowledge required
- expensive and time-consuming personal supervision
- dependent on the person
- lighting conditions related
- uncontrolled metamerism
- no repeatability
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints

EF = 7+

BASIC INSTRUMENTAL

Instrument-based comparison
to physical standard

- numerically expressed color differences
- expensive and time-consuming personal supervision
- uncontrolled metamerism
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

EF = 5-7

COLORIMETRIC AIM

Instrument-based comparison
to colorimetric standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- the possibility of remote control
- limited color definition
- only one lighting condition specified
- uncontrolled metamerism
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

EF = 4-5

SPECTRAL AIM

Instrument-based comparison
to spectral standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- lighting condition independent
- controlled metamerism
- the possibility of remote control
- trackable instrument precision and stability
- optional inter-instrument agreement harmonization

EF = 2-3

Printing
any way,
any day

Printing
same way
every day



Profitability Critical for Sustainability

75% Printers operate on less than 2% margin*

- Most Operators don't understand Profitability
 - Work hourly – do job over – no problem, more hours
- \$100 waste requires \$2000 additional sales to make up
 - Every rejected job hurts your company
- Management to provide tools and education to improve profitability
 - Help operators be accountable, rewards, feedback

* 2020 PIA Survey

Operators Instantly Know if Acceptable

Print, Measure, Simple Pass/Fail based on Color Conformance


- **Green** is salable, **Red** is not



Operators Instantly Know if Acceptable

Print, Measure, Simple Pass/Fail based on Color Conformance

- **Red** is not—- And we want to help direct operator to fix based on print technology and data!




Operators Instantly Know if Acceptable

Print, Measure, Simple Pass/Fail based on Color Conformance


- **Red** is not—- And we want to help direct operator to fix based on print technology and data!



Educating Management on Quality





Establish Minimum Quality Requirements



Continuous Performance Reports

Reporting Salability – Continuous Improvement


- Manager/Operator – KPI:
 - Dotted line shows average, only get data from their printers
- Manager only sees their printers
 - 6 Week trend line – showing improvement (lower is better)?
- Company wide initiative
 - Cloud based, automatically emailed



Custom Reports Relevant to Business

ChromaChecker API- Merges Quality data with Performance data

- Brand- Know how each provider is performing per level of work...



Where Are You In Your Journey?

Time to Transition to Print Manufacturing

- Utilize both Process Control and Color Conformance metrics
- Efficiently and effectively produce salable goods

Compliment subjective with scientific approach to communications

- Scientifically quantify customers' color expectations with E-Factor
- Concretely know and communicate device capabilities upfront

Balance Throughput with Quality

- Analyze, optimize, and maintain print ecosystem with data
- Employ single digit guidance at management, expert, and operator level
- Take full advantage of continuous print process reporting

Maximize Productivity and Profitability and Sustainability

- Produce salable color, first time every time!

Road Map Implementing Conformance

Project Inspector- Implement Color Conformance




- What Printers to Check and Monitor?
- What Project Template? GRACoL, BestBuy, GMI Other?
 - Includes which reference, brand colors, color bar, tolerance
- Measure printed color bars into respective track using favorite tool
 - Repeat for multiple locations
- Assess how salable the print is?
 - How consistent each print is to themselves over time
 - How accurate each printer is to targeted reference
 - How close each printer is to one another
 - Are brand colors within desired expectations

Where???

ROAD MAP TO ANALYTICS BASED PRINT MANUFACTURING



VISUAL ASSESSMENT • COMPARATIVE COLOR MEASUREMENT • ADVANCED COLOR MEASUREMENT



VISUAL

Personal perception-based comparison to physical standard

- no knowledge required
- expensive and time-consuming personal supervision
- dependent on the person
- lighting conditions related
- uncontrolled metamerism
- no repeatability
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints

EF = 7+

BASIC INSTRUMENTAL

Instrument-based comparison to physical standard

- numerically expressed color differences
- expensive and time-consuming personal supervision
- uncontrolled metamerism
- initial swatch-book inaccuracy
- instability of color samples
- different substrate / OBAs
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

EF = 5-7

COLORIMETRIC AIM

Instrument-based comparison to colorimetric standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- the possibility of remote control
- limited color definition
- only one lighting condition specified
- uncontrolled metamerism
- unpredictable issues of opacity, overprints and tints
- instrument precision and stability, inter-instrument agreement issues

EF = 4-5

SPECTRAL AIM

Instrument-based comparison to spectral standard

- numerically expressed color differences
- stable color definition
- exchangeable color definition
- lighting condition independent
- controlled metamerism
- the possibility of remote control
- trackable instrument precision and stability
- optional inter-instrument agreement harmonization

EF = 2-3

Printing any way, any day

Printing same way every day



Resources – Thank You

Helpful links

- TAGA CRF 95th Percentile (E-Factor) Research
https://chromachecker.com/include/img/PMG/Predict%20Color%20Image%20Match_0804-TAGA2017.pdf
- Online E-Factor Exercise
<https://chromachecker.com/cee/en/start>
- Online ΔE Spot color exercise
<https://chromachecker.com/colorexercise/en/start>
- david@chromachecker.com 651.717.0590